

# Lab 5 Notes

Tuesday, April 3, 2018 11:56 AM

- With Lab 4 (ADC), 85% of Lab 5 is done with ADC is used for reading the 2 potentiometers
- With DAC, we are going to use oscilloscope to view the output (Sine wave)
- PIC doesn't have on board DAC but QwikFlash has MAX522 chip where outputs DAC voltage through 2 pins: Out A & Out B
  - Hook up Oscilloscope to A, (Pin Headers above MAX chip)
- 2 connections to MAX
  - **DIN Pin**: Serial data input of the 16 bit Shift Register. Data clocked on rising edge of SCLK
  - **CS Pin**: Chip Select (active low): Enables data to be shifted into the 16-bit shift register. Programming commands executed on rising edge of CS
- DAC SFRs
  - SSPSTAT
  - SSPCON1
  - SSPBUF
- DAC Lecture 10 slide 21, 22
  - Only have to set bits with the red arrows, all others are ignored with zeros

## DAC

- Enable CS & DIN → Set TRIS for RC5(DIN) & RC0(CS), then in your DAC Function Set them with PORTF
  - Send Control Byte (MAX PDF in M Drive pg 9)
  - Wait for it to finish transmitting - while(SSPSTATbits.BF == 0);
  - Then send Sine wave Data - Sine wave = amplitude \* sin(2π freq time)
  - Wait for it to finish transmitting
  - Disable MAX522 chip when done
- Ext POT → 3.14159 → Int POT → (create with a loop increment by 0.001 to 1 for enough samples for a better wave)


## Sine wave

$$\text{Sine wave} = \text{amplitude} * \sin(2\pi \text{ freq time})$$




Fix it to Scale with Oscilloscope from 0V-255V

Sine wave += 5 // offset to have only positive values




Sine wave = Sine wave / 10 // Scale it down to 0V-1V



Sine wave = Sine wave \* 255 // Scale to 0-255V



Just do it in one step



- Awesome, but why are we scaling the wave?
- DIN pin takes 16-bit, 2-8 bit values.  
The software is the 2nd 8-bit value, as you may know  
... 8 bit in size  $2^8 = 256$   
So scale from 0-255